COBRA-COMMAND



PIN ASSIGNMENT

COLOR	PARTS SIDE	PIN	SOLDER SIDE	COLOR
BLACK	GROUND	1/A	GROUND	BLACK
BLACK	GROUND	2/B	GROUND	BLACK
RED	+5V	3/C	+5V	RED
RED	+5V	4/D	+5V	RED
	(NOT USED)	5/E	(NOT USED)	
ORANGE	+12V	6/F	+12V	ORANGE
	POST	7/H	POST	
WHITE/BROWN	COIN COUNTER (1)	8/J	(2) COIN COUNTER	
	(NOT USED)	9/K	(NOT USED)	
GRAY/GREEN	SPEAKER (+)	10/L	(–) SPEAKER	BLACK
	(NOT USED)	11/M	(NOT USED)	
WHITE/RED	VIDEO RED	12/N	VIDEO GREEN	WHITE/GREEN
WHITE/BLUE	VIDEO BLUE	13/P	VIDEO SYNC	WHITE/YELLOW
BLACK	VIDEO GND	14/R	SERVICE SWITCH	
	TEST SWITCH	15/S	TILT SWITCH	
GRAY	COIN 1	16/T	COIN 2	
YELLOW/BROWN	START (1P)	17/U	(2P) START	YELLOW/GREEN
YELLOW/WHITE	UP (1P) Purple	18/V	(2P) UP	PINK/WHITE
YELLOW/BLACK	DOWN (1P) Blue	19/W	(2P) DOWN	PINK/BLACK
YELLOW/RED	LEFT (1P) Green	20/X	(2P) LEFT	PINK/RED
YELLOW/ORANGE	RIGHT (1P) Yellow	21/Y	(2P) RIGHT	PINK/ORANGE
YELLOW/BLUE	SHOOT (1P) Orange	22/Z	(2P) SHOOT	PINK/BLUE
YELLOW/GRAY	BOMB (1P) Red	23/a	(2P) BOMB	PINK/GRAY
	(NOT USED)	24/b	(NOT USED)	
	(NOT USED)	25/c	(NOT USED)	
	(NOT USED)	26/d	(NOT USED)	
	GROUND	27/e	GROUND	
BLACK	GROUND	28/f	GROUND	BLACK

OPTION SWITCH SETTINGS									DIP SW #1
OPTIONS		1	2	3	4	5	6	7	8
1 COIN	1 CREDIT	OFF	OFF			OFF			
1 COIN	2 CREDITS	ON	OFF			OFF			
2 COINS	1 CREDIT	OFF	ON			OFF			
3 COINS	1 CREDIT	ON	ON			OFF			
1 COIN	1 CREDIT			OFF	OFF	OFF			
1 COIN	2 CREDITS			ON	OFF	OFF			
2 COINS	1 CREDIT			OFF	ON	OFF			
3 COINS	1 CREDIT			ON	ON	OFF			
DEMO SOUND	ON					OFF	OFF		
	OFF					OFF	ON		
SCREEN TYPE	NORMAL					OFF		OFF	
	INVERTED					OFF		ON	
GAME TYPE	COCKTAIL					OFF			OFF
	UPRIGHT					OFF			ON
		COIN A		COIN B					

OPTION SWITCH SETTINGS									DIP SW #2
OPTIONS		1	2	3	4	5	6	7	8
# OF LIVES	3	OFF	OFF					OFF	OFF
	4	ON	OFF					OFF	OFF
	5	OFF	ON					OFF	OFF
	99	ON	ON					OFF	OFF
GAME LEVEL	NORMAL			OFF	OFF			OFF	OFF
	EASY			ON	OFF			OFF	OFF
	HARD			OFF	ON			OFF	OFF
	VERY HARD			OFF	OFF			OFF	OFF
CONTINUE FEATURE	OFF					OFF		OFF	OFF
	ON					ON		OFF	OFF
EXTRA LIVES	50,000/150,000						OFF	OFF	OFF
	100,000/200,000						ON	OFF	OFF